

 iFILLSYSTEMS™

i360 Brewer

Operation & Maintenance
for Office, Hospitality, Dorms & Home Use



Safety Precautions

When using an electrical appliance, basic safety precautions should always be followed including the following:

1. Read all instructions.
 2. Do not touch hot surfaces. Use handles or knobs.
 3. To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or body in water or other liquid.
 4. Close supervision is necessary when any appliance is used by or near children.
 5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts and before cleaning the appliance.
 6. Do not operate appliance with a damaged cord or plug. If appliance malfunctions, or has been damaged in any manner, return appliance to the nearest authorized service facility for examination, repair, or adjustment.
 7. The use of accessory attachments is not recommended by manufacturer and may result in fire, electric shock, or injury to persons.
 8. Do not use outdoors.
 9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
 10. Do not place on or near a hot gas or electric burner, or in a heated oven.
 11. To disconnect, turn control to “off”.
 12. Do not use appliance for other than intended use.
 13. Scalding may occur if the lid is removed during the brewing cycles.
 14. Do not use the appliance if socket, cord, or unit is damaged.
 15. Keep instructions for reference.
- *When disposing of old machines, do not throw away. They contain materials that can be salvaged and recycled. Take to your local collection facility.*

Product Specifications



Model // i360

Voltage // AC120V

Power // 650 Watts

Capacity // Maximum 8oz

Size //


Unit // 6"w x 8"d x 11"h

Case // 18.5"w x 8.5"d x 21"h


Net Weight // 3.0 pounds

Safety Compliance // ETL approved for commercial list

Features




Operation



Open Brewer Head

Insert Pod Into Chamber




Add Water to Back Chamber

Close Brewer Head Until Click

Close Back Chamber

Place Cup Under Brew Head



Press Power Button

1. Plug cord into power supply.
2. Lift silver handle to open brewer head.
3. Insert pod into front chamber & close handle until click.
4. Add desired amount of water into back chamber & close door.
5. Place cup underneath brewer head.
6. Press the power button on the side of the brewer & the small LED light at the bottom front will turn on.
7. The unit will automatically stop after brewing is complete.

DO NOT lift the silver handle while machine is brewing.

Brew plain water before first use.

Maintenance

Outside

1. Unplug the machine and let it cool down before cleaning.
2. Use a clean damp cloth to clean all outside surfaces. Do not use harsh abrasives to clean.
3. Remove drip tray from the machine, and lift drip tray cover off the drip tray. Wash all pieces with soap and water.
4. Clean the seal around the coffee pod chamber.

****Be aware of the sharp puncture tip at the bottom of the chamber, and under the lid.***



Inside Descal

1. Fill the water tank water & household scale remover (ratio 4:1); you can also use citric acid with ratio 3%, then close the lid assembly, place the coffee cup on the drip tray, & press power button to descale the machine.
2. Empty the cup & brew water for rinsing. Run water at least twice.



Troubleshooting & Storage

Troubleshooting

1. If the indicator light keeps flashing quickly when the unit is cold & machine is powered on, the internal hardware is not working normally.

*Please contact us at 360-574-7737
CustomerCare@iFillCup.com*

2. If the indicator light keeps flashing quickly when the unit is hot & powered on, the system temperature is too high.

Wait for at least one minute to restart the unit, or pour some cold water into water tank and restart the unit.

3. When less than 2oz of water is poured into water tank, the system may not detect the water, resulting in the unit remaining in a high-temperature state, and water may not pump out.

Pour at least 3 ounces of water or more for next use.

Storage

Please store the unit out of reach of children, in a dry and clean place with no direct sunlight and away from heat sources.

** If you wish to dispose of the unit, please take it to your local recycling center.*



Service & Warranty

Service

If you have any questions please contact us at 360-574-7737 or by email at CustomerCare@iFillCup.com

Please note maintenance is NOT provided in the following circumstances:

- Improper use such as improper installation, or not using according to the instruction.
- Appliance has been disassembled by unauthorized person.
- Damages by naturally-caused wear & tear.
- Wear and tear under normal use.

90 Day Limited Warranty

This is the only express warranty for this product and is in lieu of any other warranty or condition. This product is warranted to be free from defects in material or workmanship for a 90 day period from the date of original purchase. During this period, your exclusive remedy is repair or replacement of this product or any component found to be defective, at our option; however, you are responsible for all costs associated with returning the product to us and our returning a product or component under this warranty to you.

If the product or component is no longer available, we will replace with a similar one of equal or greater value. Warranty does not cover glass, filters,

United Home Technologies LLC
 STE 107, 1101 NE 144th Street
 Suite#107 Vancouver, WA 98685
 1-360-574-7737
 Capsule Coffee Machine
 Model:i360
 AC120V 60Hz 650W
 For Hospitality Use
 CERTIFIED TO CSA
 STD.C22.2 No.64


Intertek
 4010228
 DATE CODE: 0317

DO NOT IMMERSE IN WATER
 N'INNERQE-PAB SANB L'EAU
 HOSPITALITY-USE ONLY
 AVERTISEMENT

MADE
 IN CHINA
 FABRIQUE
 EN CHINE

AUCUNE PIECE REPARABBLE. TOUTERS LES
 REPARATIONS DOIVENT ETRE EFFECTUEES
 PAR PESONNEL DE SERVICE AUTORIBE.
 RISQUE D'INCENDIE DE CHOC ELECTRIQUE
 < NE PAS QUVRIR.

Serial #: i3600117U0001

CONFORMS TO U
 STD. 1082

wear from normal use, use not in conformity with the printed directions, or damage to the product resulting from accident, alteration, abuse, or misuse. This warranty extends only to the original purchaser or gift recipient.

Proof of purchase is required to make a warranty claim. Keep the original sales receipt or copy and contact CustomerCare@iFillCup.com for questions or replacement under warranty.



Partner@iFillCup.com

Office / 360-574-7737

iFillSystems™



iFillCup®



iFillCup® & iFillSystems™

are trademarks of

United Home

Technologies, LLC.

4060 South Grant Street

Suite #106

Washougal, Washington

98671